



1861206

Deco Alarm Clock

Parts List

A.	Case	1 pc
B.	Mechanism	1 pc
C.	Battery	1 pc
D.	Back Lid	1 pc
E.	Alarm Switch	1 pc

* Please make sure that you have all the parts indicated above before you begin assembly of this item.

* This item should be assembled on a soft surface to prevent scratching the finish during assembly.

Install Battery & Adjust Settings

Parts required

A.	Case	1 pc	C.	Battery	1 pc
B.	Mechanism	1 pc	D.	Back Lid	1 pc

1. **Install Battery (C)** Turn the metal tone left or right on the Back Lid (D) to take off the Back Lid (D) from the Case (A), and install the Battery (C) into the Mechanism (B). See illustration
2. **Adjust the Time and Alarm** Use the right button on the back of the Mechanism (B) to adjust the time. Use the left button to set the alarm time. See illustration
3. **Use Alarm Switch (E)** Turn alarm on by moving Alarm Switch (E) to the left. Move Alarm Switch (E) to the right to turn alarm off. See illustration.

